

# Operating Instructions

for

## Thermal Mass Flow Meter

**Model: MAK**



We don't accept warranty and liability claims neither upon this publication nor in case of improper treatment of the described products.

The document may contain technical inaccuracies and typographical errors. The content will be revised on a regular basis. These changes will be implemented in later versions. The described products can be improved and changed at any time without prior notice.

**© Copyright**

**All rights reserved.**

## 1. Contents

---

1. Contents .....	2
2. Note .....	3
3. Instrument Inspection .....	3
4. Regulation Use .....	3
5. Operating Principle .....	4
6. Mechanical Connection .....	5
6.1 Installation and piping .....	5
7. Electrical Connection .....	7
8. Operation / Configuration / Adjustments .....	8
8.1 Warming up .....	8
8.2 Operating procedure .....	8
8.3 Zero adjustment mode .....	10
8.4 Flow rate indication .....	10
8.5 [Parameter setting mode] .....	12
9. Troubleshooting .....	17
10. Maintenance/storage .....	18
10.1 Cleaning the inlet and outlet joints .....	18
10.2 Storage .....	18
11. Technical Information .....	19
12. Order Codes .....	19
13. Dimensions .....	19
14. Disposal .....	20
15. EU Declaration of Conformance .....	21

**Manufactured and sold by:**

Kobold Messring GmbH  
Nordring 22-24  
D-65719 Hofheim  
Tel.: +49(0)6192-2990  
Fax: +49(0)6192-23398  
E-Mail: [info.de@kobold.com](mailto:info.de@kobold.com)  
Internet: [www.kobold.com](http://www.kobold.com)

## 2. Note

---

Please read these operating instructions before unpacking and putting the unit into operation. Follow the instructions precisely as described herein.

The instruction manuals on our website [www.kobold.com](http://www.kobold.com) are always for currently manufactured version of our products. Due to technical changes, the instruction manuals available online may not always correspond to the product version you have purchased. If you need an instruction manual that corresponds to the purchased product version, you can request it from us free of charge by email ([info.de@kobold.com](mailto:info.de@kobold.com)) in PDF format, specifying the relevant invoice number and serial number. If you wish, the operating instructions can also be sent to you by post in paper form against an applicable postage fee.

Operating instructions, data sheet, approvals and further information via the QR code on the device or via [www.kobold.com](http://www.kobold.com)

The devices are only to be used, maintained and serviced by persons familiar with these operating instructions and in accordance with local regulations applying to Health & Safety and prevention of accidents.

When used in machines, the measuring unit should be used only when the machines fulfil the EC machinery directive.

## 3. Instrument Inspection

---

Instruments are inspected before shipping and sent out in perfect condition.

Should damage to a device be visible, we recommend a thorough inspection of the delivery packaging. In case of damage, please inform your parcel service / forwarding agent immediately, since they are responsible for damages during transit.

### **Scope of delivery:**

The standard delivery includes:

- Thermal Mass Flow Meter      model: MAK

## 4. Regulation Use

---

Any use of the device, which exceeds the manufacturer's specification, may invalidate its warranty. Therefore, any resulting damage is not the responsibility of the manufacturer. The user assumes all risk for such usage.

## 5. Operating Principle

The new MAK series KOBOLD digital mass flowmeters have been specially developed for use in gas measurement, where excellent accuracy, high reliability, robust casing, stainless materials and maximum flexibility are important.

MAK is equipped with an indicator that employs a proven flow sensor. It has a function to indicate the integrated flow rate, in addition to the existing instantaneous flow rate indication.

A model with a flow sensor and precision needle valve in one unit is also available.


### Theory of Operation

The medium flows through the bypass measuring system. The resulting differential pressure between  $P_1$  and  $P_2$  causes a small amount of gas to flow through the overhead measuring tube. The separation ratio is constant.


Two resistance temperature detectors (RTD elements) transferring a constant amount of heat to the gas stream are mounted on the measuring tube.

Under flow conditions, the gas molecules absorb and transport the heat away. This gives rise to a temperature difference between the two detector coils, which causes a change in resistance in the detector coils, whereby  $R_1 \leftrightarrow R_2$ . The electronics converts the signal for indication. The temperature difference increases as the flow increases.

### Measuring tube design



### Flow diagram



## 6. Mechanical Connection

- (1) Use the equipment within the pressure range shown in the specification.
- (2) Use the equipment at the ambient temperature and humidity shown in the specification.
- (3) This is precision equipment. Keep it protected against strong shock.



**Caution! Do not apply a pressure exceeding the allowable level. Otherwise, the product may be damaged.**

**This product is precision equipment. Exercise caution to protect it from shocks by, for example, falling and hitting. Otherwise, the product may be damaged.**

### 6.1 Installation and piping

- Installation place
  - This equipment is designed for indoor use.  
Never install the equipment in a place where it is likely to be wetted by water or rain.  
The equipment may fail. Install the equipment in a place where sufficient ventilation is provided and changes in humidity are minimal.
  - Install the equipment in a place free of vibration and impact.
  - Do not use the equipment under direct sunlight or at high temperature/humidity.
  - Install the equipment in a place free of dust.
  - Install the product in a place free of corrosive gases.
  - Install the product in a place free of a strong electric/magnetic field.  
The frame to fix the block shall be connected to an electrically stable point (e.g. being grounded).
  - Install the product in a place where ambient temperature is 15 to 35°C.
- Lay piping so that the flow direction matches the arrow (►) shown on the body.
- Install the product horizontally.
- Install the product in such a way that the LED/switches do not face downward.
- Be sure to install a line filter (100 µm or finer) on the inlet side of gas.
- Where complete shutoff is required, provide a shutoff valve.
- To use a highly reactive gas, be sure to conduct complete purge with inert gas before and after use.

#### Installation method

Install the product with two M4 screws from the back using threaded holes on the bottom. For the location of threaded holes, see Dimensions.



## Warning!

- Never let gas exceeding the explosion limit flow to the product. Otherwise, it may cause explosion accidents
- Never use the product the gas contact part of which has not been degreased (oil-free treatment) for oxygen. Otherwise, a fire may break out. Even when the product has been degreased, if it has been used for a gas other than oxygen, never use it for oxygen.

---



## Caution!

- Ensure that no foreign matter will flow into the product. If piping rust, water droplets, oil mist, dust, etc. flow into the product, they may cause measurement/control errors and damage to the product.
- If there is a possibility that foreign matter will flow into the product, install a suitable device such as a filter, strainer and mist trap having a capacity to remove foreign matter larger than 100m in the upstream and inspect or replace it periodically.
- The needle valve of this product has not been designed for complete shutoff. If complete closing is required, please install a shutoff valve externally separately.
- Rapid heating to high temperatures can cause serious malfunctions.
- Install the product on a horizontal pipe. Ensure that the display will not face downward
- Install the product firmly so that it will not vibrate. Otherwise, it may malfunction or fail.
- After piping, inspect it to ensure that no gas will leak
- Be sure to use the product within the flow rate range defined in the product specifications. Also, in order to prevent an excessive flow rate, control the proper supply pressure and provide instrumentation in consideration of installation of a throttle valve, etc.
- If damages are envisaged due to a problem of the product, use a redundant design.

---

## 7. Electrical Connection

- Make sure that the supply wires are de-energized.
- Plug in the system according to the connecting diagrams.

**DC Jack**




Pin No.	Signal name	Description
1	Power supply COM	Power supply COM
2	Power supply +24 V	Power supply +24 V

### Connectors

Product side connector: D-subminiature 9-pin male (M2.6 short screw)  
 Applicable connectors: D-subminiature 9-pin male (M2.6 short screw)

### Pin assignment



Pin No.	Signal name	Description
1	Power supply +24 V	Power supply +24 V
2	Power supply COM	Power supply COM
3	OUT 1	Event output 1
4	OUT 2	Event output 2
5	OUT COM	Event output COM
6	Analog output	Analog output
7	TR+	RS485 communications
8	TR-	RS485 communications
9	Analog output COM TR COM	Analog output COM RS485 communications COM



**Caution! Prior to turning on the power, make sure that the product has been wired correctly.**

**Incorrect wiring will cause damage and malfunction.**


## 8. Operation / Configuration / Adjustments

### 8.1 Warming up

Warm up the equipment at least 15 minutes after it was powered on.

### 8.2 Operating procedure

#### Indicator panel



#### Indicator

Indicates an instantaneous flow rate or integrated flow rate. When lower 4 digits of the integrated flow rate are indicated, the decimal point is shown.

The decimal point is not shown for upper 4 digits.

During setting, the parameter No. or set value is shown here.

#### Event out lamps

When the Event output 1 is on, "OUT1" lights and when the Event output 2 is on, "OUT2" lights

#### Indication ID lamp

Lights when an instantaneous flow rate is being indicated and flashes when an integrated flow rate is being indicated.

**DISP key [□]**

[Measurement]

- Press: Switches over the indication. The indication switches over in the order of instantaneous flow rate → integrated flow rate (lower 4 digits) → integrated flow rate (upper 4 digits) → gas type → instantaneous flow rate. The integrated flow rate (upper 4 digits) is not indicated if the integrated flow rate value has not reached the upper 4 digits.
- Press & hold: Goes to a setting mode.
  - Pressing and holding this key when an instantaneous flow rate is being indicated shows "Parameter setting mode". Continuing to press and hold this key after "Parameter setting mode" has appeared shows "Zero adjustment mode".
  - Pressing and holding this key when an integrated flow rate is being indicated shows "Integrated flow rate resetting mode".

[Setting]

- Press: Selects items and accepts values entered in each setting mode.
- Press & hold: [Parameter setting mode] Returns to the instantaneous flow rate indication.  
[Zero adjustment mode] When <Yes> is shown, the integrated flow rate is reset.

**UP key [△]/Down key [▽]**

[Parameter setting mode]

- Press: Increase/decreases the value of the flashing digit
- Press and hold: Shifts the digit.

[Zero adjustment mode]: switching &lt;Yes&gt;/&lt;No&gt;

[Integrated flow rate resetting mode]: switching &lt;Yes&gt;/&lt;No&gt;




**Caution! This meter has been adjusted in the flow rate in the factory and adjustment data has been stored in an F-RAM. Please keep in mind that if several keys on the indicator panel are pressed and held simultaneously when turning on the power, the indicator shows the mode where the stored data will be rewritten. When the meter has entered this mode, turn off the power. If rewrite has not been enabled yet, the data may be recovered. If the data has been rewritten, it is necessary to correct the data.**


## 8.3 Zero adjustment mode

Stop the flow of gas completely with an instantaneous flow rate being indicated. In this state, pressing and holding the DISP key [□] shows “Parameter setting mode” and <F-00> will be shown. Continuing to press and hold the key shows “Zero adjustment mode” and <Yes> will be shown. Switch over <Yes>/<No> with the UP key [△]/DOWN key [▽] and when <Yes> is being shown, pressing and holding the DISP key [□] completes zero adjustment.

When <No> is being shown, pressing the DISP key [□] returns to the instantaneous flow rate indication. (If flickering of a figure near 0 is annoying, select the low cut function. The indication of a figure below 0.5% F.S. is cut.)




**Caution! If the indicated value is largely different (2% or more) from the zero point set in the factory, the zero adjustment is not possible. In this case, please contact our sales office or the dealer.**



## 8.4 Flow rate indication

### 1. Switching over flow rates to indicate


Each time the DISP key [□] on the flow rate indicator panel is pressed, indication is switched over in the order of instantaneous flow rate → integrated flow rate (lower 4 digits) → integrated flow rate (upper 4 digits) → applicable gas. The integrated flow rate (upper 4 digits) will not be indicated, however, when the integrated flow rate value has not reached the upper 4 digits.



## 2. [Integrated flow rate resetting]

In the state of integrated flow rate indication setting, press and hold the DISP key [□]. Then the indicator will show <yes>. <yes> and <no> can be switched over with the UP key[△] or DOWN key[▽].

When <yes> is being shown, pressing and holding the DISP key [□] causes <yes> to flash. When the DISP key [□] is pressed and held, the integrated flow rate value will be reset.



## 8.5 [Parameter setting mode]

When an instantaneous flow rate is being indicated, pressing and holding DISP key [□] sets the parameter setting mode. Each time DISP key [□] is pressed, the indication changes in the order of mode No. → set value → mode No. → set value.

To change the set value, use the UP key [△] or DOWN key [▽]. When the UP key [△] or DOWN key [▽] is pressed and held, the digit can be shifted.

After setting a parameter, pressing and holding DISP key [□] registers the set value and returns the mode to the flow rate indication mode.

### Default values

Mode No.	Default Value				Set Item
	A	B	C	D	
F-00	※	※	※	※	Indication of max. value (unchangeable)
P-00				※	Reference condition on flow rate
P-01				1	Low cut function selection
P-02				3	PV filter
P-03				3	Instantaneous flow rate indication update cycle
P-04				0	Integrated flow rate hold selection
P-05				※	Analog output selection
P-10			0	0	OUT1 output selection
P-11	9	9	9	9	OUT1 instantaneous flow rate upper limit preset setting
P-12	9	9	9	9	OUT1 instantaneous flow rate lower limit preset setting
P-13			3	0	Dead time value
P-14	9	9	9	9	OUT1 integrated flow rate reach preset setting upper 4 digits
P-15	9	9	9	9	OUT1 integrated flow rate reach preset setting lower 4 digits
P-16		0	1	0	Integrating pulse output rate
P-20			0	0	OUT2 output selection
P-21	9	9	9	9	OUT2 instantaneous flow rate upper limit preset setting
P-22	9	9	9	9	OUT2 instantaneous flow rate lower limit preset setting
P-23			3	0	Dead time value
P-24	9	9	9	9	OUT2 integrated flow rate reach preset setting upper 4 digits
P-25	9	9	9	9	OUT2 integrated flow rate reach preset setting lower 4 digits
P-26		0	1	0	Integrating pulse output rate
P-30				1	Applicable gas selection
P-31	1.	0	0	0	CF value
P-40				1	Communication ID
P-41				2	Transmission speed selection
P-42				0	Parity






※According to the ordered specifications

## Setting mode No. and description of set values

Mode No.	Set Item	Description of set values	Default Value								
F-00	Indication of max. value (Full scale)	<table border="1" style="margin-left: 100px;"> <tr><td>A</td><td>B</td><td>C</td><td>D</td></tr> <tr><td>2</td><td>0</td><td>0</td><td>0</td></tr> </table> <p>The value of the full scale is indicated. Unchangeable. Max value :2000</p>	A	B	C	D	2	0	0	0	※
A	B	C	D								
2	0	0	0								
P-00	Reference condition on flow rate	<table border="1" style="margin-left: 100px;"> <tr><td>A</td><td>B</td><td>C</td><td>D</td></tr> <tr><td>0</td><td></td><td></td><td></td></tr> </table> <p>Reference condition on flow rate</p> <p>0: 20°C,1atm 1: 0°C,1atm 2: 25°C,1atm</p> <p>Set the flow rate reference condition. ※The default values are as per the specifications.</p>	A	B	C	D	0				※
A	B	C	D								
0											
P-01	Low cut function selection	<table border="1" style="margin-left: 100px;"> <tr><td>A</td><td>B</td><td>C</td><td>D</td></tr> <tr><td>1</td><td></td><td></td><td></td></tr> </table> <p>Low cut function selection (<math>\pm 0.5\%</math>F.S.)</p> <p>0: Disable 1: Enable</p> <p>0:Disable: Instantaneous flow rates below 0.5% F.S. are indicated. Negative values are also indicated. 1:Enable: Instantaneous flow rates below 0.5% F.S. are indicated as 0. Negative values are also indicated as 0.</p>	A	B	C	D	1				1
A	B	C	D								
1											
P-02	PV filter	<table border="1" style="margin-left: 100px;"> <tr><td>A</td><td>B</td><td>C</td><td>D</td></tr> <tr><td>0</td><td></td><td></td><td></td></tr> </table> <p>PV filter</p> <p>0: No. 1: Moving average of sampling 2 times 2: Moving average of sampling 4 times 3: Moving average of sampling 8 times 4: Moving average of sampling 16 times 5: Moving average of sampling 32 times</p> <p>Input signals are measured during the period set here and an average value is calculated. Therefore, the indication is averaged and updated at the set cycle.</p>	A	B	C	D	0				3
A	B	C	D								
0											
P-03	Instantaneous flow rate indication update cycle	<table border="1" style="margin-left: 100px;"> <tr><td>A</td><td>B</td><td>C</td><td>D</td></tr> <tr><td>0</td><td></td><td></td><td></td></tr> </table> <p>Instantaneous flow rate indication update cycle</p> <p>0: 25ms 1: 50ms 2: 100ms 3: 200ms 4: 500ms 5: 1000ms</p>	A	B	C	D	0				3
A	B	C	D								
0											
P-04	Integrated flow rate hold selection	<table border="1" style="margin-left: 100px;"> <tr><td>A</td><td>B</td><td>C</td><td>D</td></tr> <tr><td>0</td><td></td><td></td><td></td></tr> </table> <p>(The integrated flow rate value hold cycle :1min.)</p> <p>Integrated flow rate hold</p> <p>0: disable 1: enable</p> <p>0:Disable: The integrated flow rate value is reset when the power is turned off. 1:Enable: The integrated flow rate value is held after the power is turned off. The integrated flow rate value hold cycle is 1 minute.</p>	A	B	C	D	0				1
A	B	C	D								
0											
P-05	Analog output selection	<table border="1" style="margin-left: 100px;"> <tr><td>A</td><td>B</td><td>C</td><td>D</td></tr> <tr><td>0</td><td></td><td></td><td></td></tr> </table> <p>Analog output</p> <p>0: 4-20mA 1: 0-5V 2: 1-5V</p> <p>※The default values are as per the specifications.</p>	A	B	C	D	0				※
A	B	C	D								
0											

Parameter setting No.	Set Item	Description of set values	Default Value
P-10	OUT1 output selection	<p>A B C D 0 0</p> <p>00:No 10: Instantaneous flow rate upper limit : ON 11: Instantaneous flow rate upper limit : OFF 20: Instantaneous flow rate lower limit : ON 21: Instantaneous flow rate lower limit : OFF 30: Instantaneous flow rate upper/lower limit : ON 31: Instantaneous flow rate upper/lower limit : OFF 40: Integrated flow rate reach : ON 41: Integrated flow rate reach : OFF 50: Integrating pulse : ON 51: Integrating pulse : OFF</p> <p>※ON:Normal output, OFF:Inverted output</p> <p>The function works according to results of comparison between the indicated value and the preset value. [OUT1 setting] 00:The event output mode is not used. 10:Instantaneous flow rate upper limit output     Output when "instantaneous flow rate value <math>\geq</math> P-11 upper limit preset value". 20:Instantaneous flow rate lower limit output     Output when "instantaneous flow rate value <math>\leq</math> P-12 lower limit preset value". 30:Instantaneous flow rate upper/lower limit output     Output when "instantaneous flow rate value <math>\geq</math> P-11 upper limit preset value" or "instantaneous flow rate value <math>\leq</math> P-12 lower limit preset value". ※The alarm is constantly output when "P-11 upper limit preset value <math>\leq</math> P-12 lower limit preset value" is set. 40: Integrated flow rate reach     Output when "integrated flow rate value <math>\geq</math> P-13 upper limit preset value". 50:Pulses of approx. 50 ms are output every preset value of P-16 of the integrated flow rate value.</p>	00
P-11	OUT1 instantaneous flow rate upper limit preset setting	<p>A B C D 9 9 9 9</p> <p>Setting of output 1 preset value: 0000 – 9999</p> <p>Indicated only when [10]/[11] or [30]/[31] are selected in P-10.</p>	9999
P-12	OUT1 instantaneous flow rate lower limit preset setting	<p>A B C D 0 0 0 0</p> <p>Setting of output 1 preset value: 0000 – 9999</p> <p>Indicated only when [20]/[21] or [30]/[31] are selected in P-10.</p>	0000
P-13	Dead time value	<p>A B C D 0 0</p> <p>Setting of output 1 preset value: 00~30 (unit:sec.)</p> <p>Indicated only when [10]/[11] or [20]/[21] or [30]/[31] are selected in P-10. The upper limit, lower limit and upper/lower limit are output when each condition is met during this period continuously.</p>	00
P-14	OUT1 integrated flow rate reach preset setting upper 4 digits	<p>A B C D 9 9 9 9</p> <p>(Upper 4 digits)</p> <p>Setting of output 1 preset value: 0000 – 9999</p> <p>Indicated only when [40]/[41] are selected in P-10.</p>	9999
P-15	OUT1 integrated flow rate reach preset setting lower 4 digits	<p>A B C D 9 9 9 9.</p> <p>(Lower 4 digits)</p> <p>Setting of output 1 preset value: 0000 – 9999</p> <p>Indicated only when [40]/[41] are selected in P-10. * The decimal point is shown in lower 4 digits. The position of the decimal point varies depending on specification flow rates.</p>	9999
P-16	Integrating pulse output rate	<p>A B C D 0 1 0</p> <p>Setting of output 1 preset value: 001~100(unit:%FS)</p> <p>Indicated only when [50]/[51] are selected in P-10.</p>	10

Parameter setting No.	Set Item	Description of set values	Default Value
P-20	OUT2 output selection	<p>A B C D 0 0</p> <p>00:No 10:Instantaneous flow rate upper limit : ON 11:Instantaneous flow rate upper limit : OFF 20:Instantaneous flow rate lower limit : ON 21:Instantaneous flow rate lower limit : OFF 30:Instantaneous flow rate upper/lower limit : ON 31:Instantaneous flow rate upper/lower limit : OFF 40:Integrated flow rate reach : ON 41:Integrated flow rate reach : OFF 50:Integrating pulse : ON 51:Integrating pulse : OFF</p> <p>※ON:Normal output, OFF:Inverted output</p> <p>The function works according to results of comparison between the indicated value and the preset value. [OUT2 setting] 00:The event output mode is not used. 10:Instantaneous flow rate upper limit output Output when "instantaneous flow rate value <math>\geq</math> P-21 upper limit preset value". 20:Instantaneous flow rate lower limit output Output when "instantaneous flow rate value <math>\leq</math> P-22 lower limit preset value". 30:Instantaneous flow rate upper/lower limit output Output when "instantaneous flow rate value <math>\geq</math> P-21 upper limit preset value" or "instantaneous flow rate value <math>\leq</math> P-22 lower limit preset value". ※The alarm is constantly output when "P-11 upper limit preset value <math>\leq</math> P-22 lower limit preset value" is set. 40: Integrated flow rate reach Output when "integrated flow rate value <math>\geq</math> P-23 upper limit preset value". 50:Pulses of approx. 50 ms are output every preset value of P-26 of the integrated flow rate value.</p>	00
P-21	OUT2 instantaneous flow rate upper limit preset setting	<p>A B C D 9 9 9 9</p> <p>Setting of output 2 preset value: 0000 – 9999</p> <p>Indicated only when [10]/[11] or [30]/[31] are selected in P-20.</p>	9999
P-22	OUT2 instantaneous flow rate lower limit preset setting	<p>A B C D 0 0 0 0</p> <p>Setting of output 2 preset value: 0000 – 9999</p> <p>Indicated only when [20]/[21] or [30]/[31] are selected in P-20.</p>	0000
P-23	Dead time value	<p>A B C D 0 0</p> <p>Setting of output 2 preset value: 00~30 (unit:sec.)</p> <p>Indicated only when [10]/[11] or [20]/[21] or [30]/[31] are selected in P-20. The upper limit, lower limit and upper/lower limit are output when each condition is met during this period continuously.</p>	00
P-24	OUT2 integrated flow rate reach preset setting upper 4 digits	<p>A B C D 9 9 9 9</p> <p>(Upper 4 digits)</p> <p>Setting of output 2 preset value: 0000 – 9999</p> <p>Indicated only when [40]/[41] are selected in P-20.</p>	9999
P-25	OUT2 integrated flow rate reach preset setting lower 4 digits	<p>A B C D 9 9 9 9.</p> <p>(Lower 4 digits)</p> <p>Setting of output 2 preset value: 0000 – 9999</p> <p>Indicated only when [40]/[41] are selected in P-20. * The decimal point is shown in lower 4 digits. The position of the decimal point varies depending on specification flow rates.</p>	9999
P-26	Integrating pulse output rate	<p>A B C D 0 1 0</p> <p>Setting of output 2 preset value: 001~100(unit:%FS)</p> <p>Indicated only when [50]/[51] are selected in P-20.</p>	10

Parameter setting No.	Set Item	Description of set values	Default Value
P-30	Applicable gas selection	<p>A B C D</p>  <p>Applicable gas and CF value setting</p> <p>0: CF value setting 1: N<sub>2</sub> 2: Air 3: H<sub>2</sub> 4: He 5: Ar 6: O<sub>2</sub> 7: CO<sub>2</sub> 8: CH<sub>4</sub></p>	1
		※Default:N2. FS.50～200SLM: [0]or[1]or[2]or[5], FS.300～500SLM:[0]or[1]	
P-31	CF value	<p>A B C D</p>  <p>CF value</p> <p>0.500～1.500</p>	1.000
		Indicated only when [0] is selected in P-10.	
P-40	Communication ID	<p>A B C D</p>  <p>Communication ID</p> <p>Communication ID: 1～247, -</p>	1
		[-]:Communication is disabled. [001] to [247]:Modbus conforming	
P-41	Transmission speed selection	<p>A B C D</p>  <p>Transmission speed</p> <p>0: 9600bps 1: 19200bps 2: 38400bps</p>	2
		Not indicated when [-] is selected in P-40. Fixed value: Start bit:1bit, Data length:8bit, Stop bit:1bit	
P-42	Parity	<p>A B C D</p>  <p>Parity</p> <p>0: No parity 1: Odd parity 2: Even parity</p>	0
		Not indicated when [-] is selected in P-40. Fixed value: Start bit:1bit, Data length:8bit, Stop bit:1bit	

## 9. Troubleshooting

Problem	Probable Cause	Check Item and Corrective Action
1. The indicator shows nothing.	a. The power is not on. b. The connector has not been connected to the meter properly.	1. Check to see if the power has been turned on. 1. Connect the connector properly. Check to see if the pin numbers of wires and destinations match.
2. The indication of a flow rate remains 0.	a. Gas is not flowing. b. The outlet side piping of the mass flow meter is blocked somewhere. c. The power supply is faulty. d. The sensor tube is clogged.	1. Check the source pressure of the gas cylinder and check the valve to see if it is open. 2. Check to see if the solenoid valve, three-way valve, etc. in the line are operating properly. 3. Check to see if the line filter is not clogged. 1. Check the solenoid valve, three-way valve, air valve, etc. 1. Disconnect the cable and check the voltage 24 VDC (within $\pm 5\%$ ) with a tester. If the correct voltage is not present, replace the power supply. 1. If it is clogged, gas keeps flowing. The sensor must be replaced. Please send it to our sales office or the dealer.
3. The output will not become zero (more than 45 minutes after power on).	a. The control valve is leaking internally or externally. b. The zero point of the sensor has moved. c. The sensor is faulty or the electronic circuit is faulty.	1. Disconnect the pipe before of the mass flow controller and remove gas to see if the output will become zero. 1. Conduct zero adjustment. 1. The meter may be used after zero point adjustment, but the flow accuracy will be impaired. Please send them to our sales office or the dealer for replacement.
4. The indication of a flow rate flickers when gas is flowing.	a. The supply pressure on the inlet side is constantly instable. b. The connector connection is poor. c. The power supply is faulty.	1. Install a pressure regulator on the inlet side to keep the pressure constant. 1. Check to see if the connector has been connected correctly. 1. Disconnect the cable and check the voltage 24 VDC (within $\pm 5\%$ ) with a tester. If the voltage is not stable, replace the power supply.

\* If the problem cannot be solved by the above corrective actions, please contact our sales office or the dealer.

## 10. Maintenance/storage

---

### 10.1 Cleaning the inlet and outlet joints

When removing the joints for cleaning, conduct the work in clean environment so that no dust and dirt will enter the product. However, never disassemble or overhaul the product nor remove the protective seals.

If the product has been disassembled or overhauled or the protective seals have been removed, it is considered that the user has waived his/her right to warranty even within the warranty period.

### 10.2 Storage

If the product is not put in use for a long time after it was received, unexpected troubles may occur.

When it is expected that the product will be kept in storage for a long time, take the following precautions:

- (1) Store the product in the package in which it was received from Kobold, wherever possible.
- (2) Store the product in a place described below:
  - ① A place free of rain and water.
  - ② A place free of vibration and impact.
  - ③ A place of normal temperature and normal humidity (around 25°C, 65%).
  - ④ A place free of dust.
  - ⑤ A place free of corrosive gases.
  - ⑥ A place free of a strong electric/magnetic field.
- (3) To store the product that has been used, purge it with clean air or N<sub>2</sub> so that measuring gas will not remain in the flow meter. Cover the inlet and outlet sides (joints) of measuring gas with caps to prevent intrusion of dust and dirt.

## **11. Technical Information**

---

Operating instructions, data sheet, approvals and further information via the QR code on the device or via [www.kobold.com](http://www.kobold.com)

## **12. Order Codes**

---

Operating instructions, data sheet, approvals and further information via the QR code on the device or via [www.kobold.com](http://www.kobold.com)

## **13. Dimensions**

---

Operating instructions, data sheet, approvals and further information via the QR code on the device or via [www.kobold.com](http://www.kobold.com)

## 14. Disposal


---

### **Note!**

- Avoid environmental damage caused by media-contaminated parts
- Dispose of the device and packaging in an environmentally friendly manner
- Comply with applicable national and international disposal regulations and environmental regulations.

### **Batteries**

Batteries containing pollutants are marked with a sign consisting of a crossed-out garbage can and the chemical symbol (Cd, Hg, Li or Pb) of the heavy metal that is decisive for the classification as containing pollutants:



1. „Cd“ stands for cadmium
2. „Hg“ stands for mercury
3. „Pb“ stands for lead
4. „Li“ stands for lithium

### **Electrical and electronic equipment**



## **15. EU Declaration of Conformance**

We, KOBOLD Messring GmbH, Hofheim-Ts, Germany, declare under our sole responsibility that the product:

**Thermal Mass Flowmeter      Model: MAK**

to which this declaration relates is in conformity with the standards noted below:

**EN 61326-1:2013** Electrical equipment for measurement, control and laboratory use - EMC requirements - Part 1: General requirements

**EN 61326-2-3:2013** Electrical equipment for measurement, control and laboratory use - EMC requirements - Part 2-3: Particular requirements - Test configuration, operational conditions and performance criteria for transducers with integrated or remote signal conditioning

**EN IEC 63000:2018** Technical documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances

Also, the following EC guidelines are fulfilled:

**2014/30/EU**      **EMC Directive**

**2011/65/EU**      **RoHS (category 9)**

**2015/863/EU**      **Delegated Directive (RoHS III)**



Hofheim, 06 April 2023

H. Volz  
General Manager

M. Wenzel  
Proxy Holder